

QR FITTING INSTRUCTIONS

Step by Step (QR1) v2 24-02-06



Out with the old...

If you have a battery connected then take it out – you'll need the elbow room later. In addition, you do not want to be working in the control box with a battery connected!



Remove the boot

This may not be applicable to some C5's where these parts have already been removed. However, on the inside edge (nearest the tyre) of the plastic body there may be two black clips holding the boot swivel point. These simply pull off like circlips. Once these are removed, the boot can be taken off by pulling the wheel arch outwards slightly until the pivot points are free and then the boot should slide downwards towards the ground to be removed.

Remove the old wiring

Trace the blue and brown wires from the old power block (that you put the key in). They go through the rubber grommet under the seat and to the control box. You may need to remove some cable ties to get the wiring out. If you are not sure skip this section and simply pull the wiring through from the footwell and when you come to remove the wires (in the next section) from the control box, simply cable tie them out of the way. This method, although untidy, will allow you to put the machine back to standard somewhat quicker, should you ever want/need to.

