



Switch from C5 (not supplied)

(W2)

FAN RETAINING RING

(W1)

BATTERY 1

BATTERY 2

(W4)

(W5)

(W3)

CONTROLLER AND FAN  
NUTS, BOLTS & WASHERS

(W6)

CABLE TIES

FAN MOUNTING PLATES X4

**Separate pages are shown for wiring diagrams (W1) - (W6)**

